



| Ref. N. | Description |
|---------|---------------------------------|
| 1000 | Pump Casing |
| 1001 | Pump fixing plate |
| 1002 | Draining and priming cap |
| 1003 | Tie bolt |
| 1004 | Kit nuts and washers |
| 2000 | Outer case |
| 2001 | Mechanical seal housing |
| 2002 | Motor flange |
| 2003 | Motor bracket |
| 2004 | Coupling guard |
| 2005 | Filling plug |
| 2006 | Kit circlip and bearing |
| 2007 | Kit coupling washers and screws |
| 2008 | Coupling |
| 2009 | Kit motor screws |

| Ref. N. | Description |
|---------|---|
| 3000 | Pump shaft |
| 3001 | Kit mechanical seal |
| 3002 | Kit screws, nuts and washers |
| 3003 | Kit o-ring (4 pcs) |
| 4000 | Stage housing and diffuser |
| 4001 | Stage centering outlet |
| 4002 | Floating neck ring assembly |
| 4003 | Initial stage housing |
| 4004 | Last stage with diffuser |
| 4005 | Stage centering inlet |
| 4006 | Stage housing and diffuser with bearing |
| 5000 | Impeller |
| 5001 | Impeller spacers (2 pcs) |
| 5002 | Intermediary sleeve |
| 5003 | Intermediary sleeve spacers (2 pcs) |